



ROLLED RUBBER FLOORING INSTALLATION GUIDE - GENERAL RECOMMENDATIONS • INSTALLATION TOOLS CHECKLIST SUBFLOOR REQUIREMENTS • SHEET INSTALLATION • PRODUCT WARRANTY

GENERAL RECOMMENDATIONS

1. Read all product and subfloor preparation instructions, adhesive instructions, warranty and other disclaimers BEFORE you begin to install All South Flooring rolled rubber flooring.

2. The installation surface and rubber rolls need to be clean and dry prior to installation. Subfloors to be installed with rubber roll goods should be maintained at a consistent temperature from 24 to 48 hours before, during and after the installation. All South Flooring recommends an optimum temperature of 68°F (18°C) be maintained in the installation area.

3. Room temperature variations can affect rubber roll goods as the material can expand (warm) or contract (cold). Temperature requirements for the flooring adhesive should be reviewed as well.

4. Prior to starting any installation, thoroughly review rubber roll goods. Verify the following for roll goods:

- Material type, material color and style are correct
- Material is supplied at the correct size and thickness
- Amount of material supplied is correct
- No visual defects are present on the material

Note: Skive/knife marks on product is an inherent characteristic of using recycled rubber and is not considered a defect.

***** IMPORTANT *** ANY suspect or defective material must be brought to the attention of the supplier immediately. ABSOLUTELY NO CLAIMS WILL BE ACCEPTED AFTER THE MATERIAL HAS BEEN INSTALLED.**

5. All South Flooring rubber roll goods are wound tightly upon packaging and will retain a certain amount of memory when unrolled. The rolled rubber (and adhesive) should be acclimated to the installation room temperature for 24 hours. Allow additional time in colder temperatures or use room heaters to bring up the ambient air temperature. If heaters are used, be sure to maintain a consistent temperature throughout the installation process. See step 2 above.

6. If the rolled rubber material is stored prior to installation, always lay the rolls on their side. Rolled rubber stored on end will result in curled edges. Edge curl will result in raised seams and potential trip hazards. Always store rubber material on a clean, dry and surface. All South Flooring recommends storing rolled rubber flooring at a minimum of 55°F (13°C) with less than 50% humidity.

7. For best results, All South Flooring recommends using their "99/12" adhesive or a one-part polyurethane adhesive to glue the rolled rubber to the subfloor. Ask your All South Flooring sales representative for the approved adhesive.

***** IMPORTANT *** DO NOT use petroleum-based products in conjunction with All South Flooring rolled rubber flooring. This includes solvents, adhesives or sealants.**

8. An adhesive bond test should be completed in several locations across the floor. Glue down 2' x 2' pieces of material with recommended adhesive and trowel and let set for 48 hours before trying to remove. The squares should be relatively difficult to pull up and there should be adhesive on the floor and rubber square.

9. Rolled Rubber flooring that is loose-laid in the installation area (to acclimate to room temperature), or permanently installed, should be securely covered with a tarpaulin or other protective material when other trade professionals are working in the area. If possible, install the material after all other work is completed in the immediate installation area.



RECOMMENDED INSTALLATION TOOLS

- Rubber gloves
- "99/12" Adhesive
- Safety glasses
- 75 lb. sectional roller
- Knee pads
- Metal carpenter's square
- Utility knife
- Measuring tape
- Extra knife blades
- Chalk line
- Adhesive trowel
- Pen or Marker (1/16"x1/16"x3/32")
- Tarpaulin

SUBFLOOR REQUIREMENTS FOR INSTALLATION

1. All South Flooring's rolled rubber flooring may be installed over concrete, cement-type leveling bases, asphalt and wood subfloors.
2. All subfloors should be thoroughly cleaned, and primed. Remove all paint, varnish, oil, grease, dust, wax or any foreign substance that may decrease the bond strength of the polyurethane flooring adhesive. (Review ASTM 710 for more information.)
3. Verify the sub is dry, smooth and level. Subfloor surfaces should not vary more than 1/8" in ten feet.
4. Gypsum patching compounds and leveling products should not be used on subfloor surfaces with the exception of USG Advanced Skim Coat.
5. Stabilization of the subfloor is the sole responsibility of the installer and/or property owner.



CONCRETE (OR LEVELED CEMENT-TYPE) SUBFLOORS

1. Concrete surfaces must be thoroughly cured, free from hydrostatic pressure, leveled and cleaned from any foreign materials such as dust, dirt, paint, oil and water prior to rubber tile installation.
 - Use a trisodium phosphate solution (or Xylol for rubber-based paint) to remove oil, grease or wax. • Remove paint, old adhesive or other foreign material by either machine sanding or scraping. • Thoroughly wash and rinse treated areas. Allow subfloor to completely dry.
2. To reduce the amount of adhesive required, concrete surfaces should be reasonably smooth.
3. Any separation of concrete layers, heaving, etc. is the sole responsibility of the installer and/or property owner.
4. Allow for good drainage of the installation area with either a well-defined gradient (1% or greater depending on the coverage size of the surface) or well-placed drainage pipe in lower spots of the area.
5. The existing concrete surface shall be free of significant cracks or gaps prior to the installation. Patch areas with a latex-based leveling/ compound according to the manufacturer's guidelines. Allow compound to dry as directed.
6. New concrete, or the alike, should be allowed to cure for a minimum of 60 days prior to installing All South Flooring rolled rubber flooring. The surface should be smooth and level.
7. Both moisture and pH tests should be conducted on concrete subfloors to determine if they are suitable for installation. Moisture should not exceed 3 lbs./1000 sq. ft. and pH level should be 7-10. (Review ASTM F1869 for water vapor emissions.)

WOOD SUBFLOORS

1. The wood subfloor should be in good condition, rigid, and free from movement. The subfloor should have good cross ventilation under the floor to prevent distortion.
2. The wood surface should be clean and free from any foreign materials such as dust, dirt, paint or protruding nails and screws. All damaged wood should be replaced.
3. The surface should be leveled, clean and dry before application. Trapped moisture may cause deterioration and premature rotting of the wood. The sub should be free from excessive cupping or warping.
4. The existing wooden surface shall be free of significant cracks or gaps prior to the installation. Patch areas with a plastic wood compound according to the manufacturer's guidelines. Allow compound to dry as directed.
5. Re-nail all loose boards. Replace worn or damaged boards. If necessary, sand floors to a level finish and prime. Wood subfloors can also be covered with a five-ply 5/8" (15.875mm) plywood or hardboard. Prime newly replaced floorboards.



ASPHALT SUBSURFACES

1. Asphalt subfloor surfaces must be hard enough not to melt during hot weather, leveled, and free from any foreign materials such as grease, oil, dust, paint and other contaminants. Avoid installation of rolled rubber flooring on new asphalt until surface oil has had time to dissipate (Approx. 30 days after compacting) and drainage can be evaluated.
2. Any separation of asphalt or blacktop layers, heaving etc. is the sole responsibility of the installer and/or property owner.
3. Allow for good drainage of the installation area with either a well-defined gradient (1% or greater depending on the coverage size of the surface) or well-placed drainage pipe in lower spots of the area.
4. The existing asphalt surface shall be free of significant cracks or gaps prior to the installation. Fill cracks and gaps to level surface.
5. All rolled rubber flooring installed on asphalt must be adhered using "99/12" or a polyurethane adhesive. Please contact your All South Flooring sales representative for approved adhesives.



INSTALLATION INSTRUCTIONS

1. Beginning along a straight wall, lay the first sheet of flooring. If the walls are not square, use a chalk line to lay the sheet.
2. Apply adhesive using a 1/16" x 1/16" x 3/32" U-notch trowel. Spread adhesive perpendicular to seam areas to prevent excess adhesive from protruding through the seam. Use a new trowel for each new pail of adhesive. DO NOT RE-NOTCH THE TROWEL.
3. **Review the flooring adhesive manufacturers usage guidelines for spread rate and open times for curing.** Higher temperatures and high humidity will cause the adhesive to set up quickly. Low temps and low humidity will cause the adhesive to set at a slower rate. The installer should monitor on-site conditions and adjust accordingly. DO NOT LET ADHESIVE SKIM OVER.
4. Fold the first roll lengthwise (half the width of the roll) and spread the adhesive over the subfloor using the approved trowel.
5. Lay the material into the wet adhesive carefully. Dropping rubber sheet into adhesive will trap air under the flooring.
6. Immediately roll the rubber flooring with a 75 lb. roller. Roll the width first, then the length. Roll flooring again in 30-45 minutes.

Failure to roll the sheet while the adhesive is still soft is the second major cause of bonding failure.

BANKED TURNS: Immediately after rolling, weigh down the flooring with sandbags to allow the rubber to conform to the subfloor contour.

7. Repeat steps #4 through #6 for the second half of the first sheet.
8. Position the second sheet against the first sheet. Do not place pressure on the first sheet as the glue will still be wet and may shift the sheet. Verify there are no gaps between the rubber sheets and the seams are tight.
9. Continue to place the rubber material adjacent to the previous sheet laid until the entire floor is covered. Immediately roll each sheet with a 75 lb. roller.
10. Hand roll all seams after the floor has been rolled. If there is some gapping in the seams, masking tape (3M "Long Mask" #2090 is preferred) can be used to pull the seams together. DO NOT USE DUCT TAPE as it may leave a residue. Once the floor has set the tape may be removed.
11. If adhesive pushes up in the seams, immediately clean with a damp rag and mineral spirits. Cured adhesive on the floor is very difficult to remove. All South Flooring strongly recommends using gloves when applying adhesive.

***** IMPORTANT *** DO NOT ALLOW** foot traffic or rolling loads on the newly installed floor for a minimum of 24 hours. Permanent indentations in the adhesive could result and prevent a secure bond to the sub r. For maximum strength, allow adhesive to cure for 72 hours.



POST INSTALLATION INSTRUCTIONS (Continued)

All South Flooring rolled goods do not include a protective finish when shipped from the manufacturing facility. It is highly recommended that the newly installed rubber floor be protected using a tarpaulin or other cover until the floor can be cleaned and/or sealed.

INITIAL CLEANING: Do not wash the floor for at least 5 days after installation. An initial cleaning needs to be done to remove any dirt and grit from the job site and to prepare the floor prior to applying a sealer or finish. Failure to clean properly will cause bonding issues as well as the entrapment of dirt in the floor.

To avoid possible damage to the flooring, the following should never be used on the floor:

- Steel wool or abrasive brushes
- Abrasive or alkaline cleaners
- Solvents of any type.



DISCLAIMER

The All South Flooring Rolled Rubber Flooring Installation Guide represents typical installation methods. Generally accepted installation practices should be followed. Use of a trained installation professional is recommended for best results. All South Flooring does not warrant any installation work and specifically disclaims liability for any direct or indirect personal injury, property damage or other costs or losses resulting from incorrect or inadequate installations.

All South Flooring shall warranty the flooring materials it has supplied to be free from manufacturing defects in MATERIAL ONLY for a period of one (1) year from date of substantial completion and the flooring contractor shall warrant the installation to be free from defects for the same period.

The foregoing warranty is in lieu of and excludes all other warranties not expressly set forth herein, whether express or implied, including, but not limited to any implied warranties of merchantability or fitness.

Skive/knife marks on product is an inherent characteristic of using recycled rubber and will not be viewed as an appropriate reason for rejecting the product.

All South Flooring and its contractors shall not be liable for incidental or consequential losses, damages, or expenses, directly or indirectly arising from the sale, handling or use of the goods, or from any other cause relating thereto, and their liability hereunder in any case is expressly limited to the replacement of goods of complying with this agreement, or, at their election, to the repayment of, or crediting Buyer with, an amount equal to the purchase price of such goods, whether such claims are for breach of warranty negligence.